

---

Meridian 1

# Digital Trunk Interface/Computer-to-PBX Interface

Installation and data administration

---

Document Number: 553-2811-200

Document Release: Standard 6.0

Date: December 1994

---

© 1991, 1994

All rights reserved

Printed in the United States of America

Information is subject to change without notice. Northern Telecom reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant. This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC rules.

SL-1 and Meridian 1 are trademarks of Northern Telecom.

---

# Revision history

---

**September 16, 1991**

Standard, release 1.0. Reissued for compliance with Northern Telecom standard 164.0.

This document has been merged with *DTI/CPI wire list* (553-2811-200 Appendix 1). The information previously contained in that document is now contained in the chapter, “Wire list,” in this document.

**December 1, 1991**

Standard, release 2.0. This document is reissued to include technical content updates. Due to the extent of the changes, revision bars are omitted.

**December 31, 1992**

Standard, release 3.0. This document is issued to include technical updates. Changes are noted with revision bars in the margins.

**August 1, 1993**

Standard, release 4.0. This document is reissued for updates and changes resulting from X11 release 19. All updates are noted with revision bars in the margins.

**October 31, 1993**

Standard, release 5.0. This document has been reorganized to enhance ease of use and updated to reflect current technical information. Technical changes are noted with revision bars in the margins.

**December 1994**

Standard, release 6.0. Reissued to include editorial changes and indexing. Due to the extent of the changes, revision bars are not used.

---

# Contents

---

|                                                   |          |
|---------------------------------------------------|----------|
| <b>Introduction</b>                               | <b>1</b> |
| Other documentation                               | 2        |
| <b>DTI installation</b>                           | <b>3</b> |
| Equipment overview                                | 3        |
| DTI interfaces                                    | 4        |
| QPC472 DTI specifications                         | 4        |
| QPC720 PRI specifications                         | 7        |
| Cable requirements                                | 10       |
| Installation procedures                           | 11       |
| Removing the DTI card                             | 15       |
| ST, STE systems                                   | 15       |
| MS systems                                        | 18       |
| N/NT and RT systems                               | 20       |
| XN/XT systems                                     | 24       |
| 21A, 21, 51, 61, 71, and 81                       | 26       |
| Echo Canceller interface                          | 27       |
| Clock Controller installation                     | 28       |
| Determining slots and shelves                     | 29       |
| Replacing a Clock Controller                      | 32       |
| Installing a Clock Controller                     | 32       |
| Starting the Clock Controller                     | 32       |
| Clock Controller commands                         | 33       |
| Installing the Clock Controller in a single group | 36       |

|                                                           |           |
|-----------------------------------------------------------|-----------|
| Cabling requirements .....                                | 40        |
| NT8D74 Clock Controller to InterGroup cable .....         | 40        |
| NT8D75 Clock Controller to Clock Controller cable .....   | 40        |
| NT8D79 PRI/DTI to Clock Controller cable .....            | 41        |
| <b>Data administration .....</b>                          | <b>43</b> |
| DTI data administration .....                             | 44        |
| CPI data administration .....                             | 51        |
| <b>Acceptance tests .....</b>                             | <b>53</b> |
| Self-test procedures .....                                | 53        |
| Automatic loop test .....                                 | 54        |
| Automatic loop test procedures .....                      | 54        |
| Link diagnostic and remote loopback tests .....           | 55        |
| Link diagnostic and remote loopback test procedures ..... | 56        |
| <b>Wire list .....</b>                                    | <b>57</b> |
| QCAD129/NT9J93xx .....                                    | 57        |
| QCAD133/NT8D97xx .....                                    | 59        |
| QCAD128/NT8D83xx .....                                    | 60        |

---

## List of figures

---

|                                                                    |    |
|--------------------------------------------------------------------|----|
| Figure 1                                                           |    |
| QPC472 DTI faceplate layout .....                                  | 6  |
| Figure 2                                                           |    |
| QPC720 PRI faceplate layout .....                                  | 9  |
| Figure 3                                                           |    |
| ST, STE cabling arrangement .....                                  | 16 |
| Figure 4                                                           |    |
| Switch settings in DTI mode .....                                  | 17 |
| Figure 5                                                           |    |
| Switch settings in DTI mode .....                                  | 18 |
| Figure 6                                                           |    |
| MS cabling arrangement .....                                       | 19 |
| Figure 7                                                           |    |
| Switch settings in DTI mode .....                                  | 20 |
| Figure 8                                                           |    |
| N/NT, 51, RT, and 61 single and half group cabling arrangement ... | 21 |
| Figure 9                                                           |    |
| Switch settings in DTI mode .....                                  | 24 |
| Figure 10                                                          |    |
| XN/XT and 71 cabling arrangement .....                             | 25 |
| Figure 11                                                          |    |
| DTI-to-Echo Cancellor cabling .....                                | 26 |
| Figure 12                                                          |    |
| DTI remote loopback test and DTI link diagnostic test .....        | 56 |

---

## List of tables

---

|                                                                                                             |    |
|-------------------------------------------------------------------------------------------------------------|----|
| Table 1                                                                                                     |    |
| QPC472 transmission equalization SW2 switch settings for DTI . . . .                                        | 5  |
| Table 2                                                                                                     |    |
| QPC472 DTI external connectors . . . . .                                                                    | 5  |
| Table 3                                                                                                     |    |
| QPC720 transmission equalization SW2 switch settings<br>for PRI/DTI . . . . .                               | 7  |
| Table 4                                                                                                     |    |
| SW3 options for the QPC720 PRI/DTI . . . . .                                                                | 8  |
| Table 5                                                                                                     |    |
| QPC720 PRI external connectors . . . . .                                                                    | 8  |
| Table 6                                                                                                     |    |
| DTI cables and cable lengths . . . . .                                                                      | 10 |
| Table 7                                                                                                     |    |
| Possible card locations by system . . . . .                                                                 | 11 |
| Table 8                                                                                                     |    |
| Cable connections to the Clock Controller, Network, Patch panel,<br>I/O panel, and Echo Canceller . . . . . | 12 |
| Table 9                                                                                                     |    |
| DTI-to-Echo Canceller pin assignments . . . . .                                                             | 27 |
| Table 10                                                                                                    |    |
| Operating parameters for the Echo Canceller . . . . .                                                       | 27 |
| Table 11                                                                                                    |    |
| Settings for the 24 channels on the Echo Canceller . . . . .                                                | 28 |

|                                                                                        |    |
|----------------------------------------------------------------------------------------|----|
| Table 12                                                                               |    |
| Clock Controller shelves and slots . . . . .                                           | 29 |
| Table 13                                                                               |    |
| Clock Controller switch settings for QPC471 vintage A . . . . .                        | 29 |
| Table 14                                                                               |    |
| Clock Controller switch settings for QPC471 vintages B, C, D, E,<br>F, and G . . . . . | 30 |
| Table 15                                                                               |    |
| Clock Controller switch settings for QPC471 vintage H . . . . .                        | 31 |
| Table 16                                                                               |    |
| Clock Controller switch settings for QPC775 . . . . .                                  | 31 |
| Table 17                                                                               |    |
| QCAD129/NT9J93xx wire list . . . . .                                                   | 58 |
| Table 18                                                                               |    |
| QCAD133/NT8D97xx wire list . . . . .                                                   | 59 |
| Table 19                                                                               |    |
| QCAD128/NT8D83xx wire list . . . . .                                                   | 60 |